



KS

► Assembly, installation and operating instructions

Keep these instructions in a safe place for future use!

Table of contents

1 General	4
1.1 About these instructions	4
1.2 Explanation of Symbols.....	4
2 Safety	5
2.1 Correct use.....	5
2.2 Limits of operation and use	5
2.3 Personnel requirements - Qualifications	6
2.4 Personal Protective Equipment	6
3 Transport, storage and packaging	7
3.1 General transport instructions	7
3.2 Scope of delivery.....	7
3.3 Storage	8
3.4 Packaging	8
4 Construction and function	9
4.1 Overview.....	9
4.2 Brief description.....	9
4.3 Dimensions/Nominal lengths	10
5 Installation and wiring	11
5.1 Requirements governing the installation site.....	11
5.2 Installation.....	11
5.2.1 Installation situation (unit installed).....	11
5.2.2 Installing KS in a dry wall	11
5.2.3 Adjusting the eccentric rollers	13
5.2.4 Adjusting the optional volumetric flow limiter	14
6 Pre-commissioning checks	15
7 Maintenance	16
7.1 Clean the inside of the unit.....	16
7.2 Cleaning the volumetric flow limiter	16

KS

Lüftungskomponenten, Kombinationsschlitzdurchlass

Assembly, installation and operating instructions

1 General

1.1 About these instructions

These instructions ensure the safe and efficient handling of this equipment. These instructions form an integral part of the equipment and have to be kept in the direct vicinity of the equipment and available to personnel at all times.

All personnel must have carefully read through these instructions prior to commencing all work on the equipment. A fundamental prerequisite for safe working is compliance with all the stated safety instructions and other instructions contained in this manual.

In addition all local occupational health and safety at work regulations apply, as do general safety provisions governing the use of the equipment.

Illustrations in this guide are intended to provide a basic understanding and may differ from the actual model.

Ongoing tests and further developments may result in small variations between the unit supplied and the instructions.

1.2 Explanation of Symbols



WARNING!

This combination of symbol and signal word indicates a possible hazardous situation.



IMPORTANT NOTE!

It represents a potentially hazardous situation, which could lead to damage to property or for a measure to optimise workflows.



IMPORTANT NOTE!

This symbol highlights useful hints, recommendations and information for efficient and trouble-free operation.

2 Safety

This section provides an overview of all important safety aspects to ensure optimum protection of personnel as well as safe and trouble-free operation. In addition to the safety instructions in these operating instructions, the valid safety, accident prevention and environmental protection regulations must be observed for the area of use of the unit. It is the duty of the operator to ensure that instructions relating to maintenance (e.g. relating to hygiene) are complied with.

2.1 Correct use

Intended use of the unit also includes adherence to these instructions.

Information in accordance with EN60335-1

- ▶ This unit can be used by children aged 8 years or more and also by people with reduced physical, sensory or mental capabilities or a lack of experience and knowledge, if they are supervised or have been instructed in the safe use of the unit and the resulting dangers. Do not allow children to play with the unit. Do not allow children to clean and maintain the unit without supervision.
- ▶ This unit is not intended for permanent connection to the drinking water supply system.
- ▶ This unit is intended for being accessible to the general public.

Any use beyond or other than the stated intended use is considered as misuse.

Any change to the unit or use of non-original spare parts will cause the expiry of the warranty and the manufacturer's liability.

2.2 Limits of operation and use

Variable	Value	Unit
Temperature range	0 – 50	°C
Max. relative air humidity	90	%



IMPORTANT NOTE!

Warning of misuse!

In the event of misuse, as itemised below, there is a danger of limited or failing operation of the unit. Ensure that the airflow can circulate freely.

- ▶ Never operate the unit in humid areas, such as swimming pools, wet areas etc.
- ▶ Never operate the unit in rooms with an explosive atmosphere.
- ▶ Never operate the unit in aggressive or corrosive atmospheres (e.g. sea air).

KS

Lüftungskomponenten, Kombinationsschlitzdurchlass

Assembly, installation and operating instructions

2.3 Personnel requirements - Qualifications

Expertise

The installation of this product requires specialist knowledge of heating, cooling, ventilation, installation and electrical engineering. This knowledge, generally learned in professional training in one of the fields mentioned above, is not described separately.

Damage caused by improper installation is the responsibility of the operator or installer. The installer of these units should have adequate knowledge of the following gained from specialist professional training

- ▶ Safety and accident prevention regulations
- ▶ Guidelines and recognised technical regulations, i.e. Association of German Electricians VDE regulations, DIN and EN standards.
- ▶ VDI 6022; maintenance personnel must be trained to Category B (possibly Category C) to comply with hygiene requirements (as required).

The installation, operation and maintenance of this unit must comply with the applicable laws, standards, provisions and regulations in the respective country and the current state of the art.

2.4 Personal Protective Equipment

Personal protective equipment is used to protect people from impaired safety and health when working with the unit. The applicable accident prevention regulations at the place of use apply in all cases.

Personnel have to wear personal protective equipment during maintenance and troubleshooting on and with the unit.

3 Transport, storage and packaging

3.1 General transport instructions

Check on delivery for completeness and transport damage.

Proceed as follows in the event of visible damage:

- ▶ Do not accept delivery or only accept with reservations.
- ▶ Record any transport damage on the transportation documents or on the transport company's delivery note.
- ▶ Submit a complaint to the freight forwarder.



IMPORTANT NOTE!

Warranty claims can only be made within the applicable period for complaints. (More information is available in the T&Cs on the Kampmann website)



IMPORTANT NOTE!

2 people are needed to transport the unit. Wear personal protective clothing when transporting the unit. Only lift the unit on both sides and not by the pipes / valves.



IMPORTANT NOTE!

Material damage caused by incorrect transport!

Units being transported can drop or topple over if transported wrongly. This can cause serious material damage.

- ▶ Proceed carefully when unloading the equipment on delivery and when transporting it on site and note the symbols and instructions on the packaging.
- ▶ Only use the holding points provided.
- ▶ Only remove packaging shortly before assembling the unit.

3.2 Scope of delivery



IMPORTANT NOTE!

Check the scope of delivery!

- ▶ Check the delivery for damage.
- ▶ Check that the articles and type numbers are correct.
- ▶ Is the delivery and number of items delivered correct?

KS

Lüftungskomponenten, Kombinationsschlitzdurchlass

Assembly, installation and operating instructions

3.3 Storage

Store packaging under the following conditions:

- ▶ Do not store outdoors.
- ▶ Store in a dry and dust-free place.
- ▶ Store in a frost-free place.
- ▶ Do not expose to aggressive media.
- ▶ Protect from direct sunlight.
- ▶ Avoid mechanical vibrations and shocks.



IMPORTANT NOTE!

Under certain circumstances, packages can carry storage instructions that exceed the requirements listed here. Comply with these instructions accordingly.

3.4 Packaging

Handling packaging materials



IMPORTANT NOTE!

Dispose of packaging materials in line with the applicable statutory requirements and local regulations.

4 Construction and function

4.1 Overview




Fig. 1: KS at a glance

1	Air outlet front	2	Extract air spigot
3	Supply air spigot	4	Acoustic insulation backing (building material class B1)
5	Partition between supply air and extract air	6	Eccentric rollers in supply air
7	Nozzle rollers in extract air		

4.2 Brief description

The KS is a combined diffuser for use in and behind drywalls and cladding. The diffuser combines a supply and extract air opening in a single system. The visible outlet front runs continuously so that the opening has the appearance of a continuous slot. The KS can optionally be equipped with flow limiters in the supply and extract air spigots.

KS

Lüftungskomponenten, Kombinationsschlitzdurchlass

Assembly, installation and operating instructions

4.3 Dimensions/Nominal lengths




Fig. 2: Views of KS
(All figures in mm)

Dimensions	Nominal length 550 [mm]	Nominal length 750 [mm]	Nominal length 950 [mm]	Nominal length 1150 [mm]
A (air outlet front)	550	750	950	1150
B (width of junction box)	517	717	917	1117
E (diameter of spigot)	98	98	98	98

Tab. 1: Dimensions of available nominal lengths

① Example (optional): spigot with built-in volumetric flow control

5 Installation and wiring

5.1 Requirements governing the installation site

Only install and assemble the unit if the following conditions are met:

- ▶ Make sure that the wall/ceiling is sufficiently load-bearing to take the weight of the unit (Technical data).
- ▶ Make sure that the ceiling is sufficiently load-bearing to take the weight of the unit (Technical data).
- ▶ Make sure that the unit is securely suspended/standing.
- ▶ Ensure that the airflow can circulate freely.

5.2 Installation

2 people are needed to install the unit.



CAUTION!

Risk of injury from sharp metal housing!

The inner metal of the casing can have sharp edges.

- ▶ Wear suitable protective gloves.

5.2.1 Installation situation (unit installed)




Fig. 3: Example of installation situation

- ▶ Provide bracket fixings ① by others.

KS

Lüftungskomponenten, Kombinationsschlitzdurchlass

Assembly, installation and operating instructions

5.2.2 Installing KS in a dry wall

Provide the following opening in the dry wall element before installing the KS:




Fig. 4: Dimensions of the installation opening [mm]

Dimensions	Nominal length 550 [mm]	Nominal length 750 [mm]	Nominal length 950 [mm]	Nominal length 1150 [mm]
A	521	721	921	1121
B	154	154	154	154

Installing the KS




Fig. 5: Suggested installation of the KS (suspended with threaded rods)

1	Installation brackets (by others)	2	Air outlet front
---	-----------------------------------	---	------------------




Fig. 6: Note the installation areas!

- ▶ Do not screw the installation brackets into the areas marked with a *!




Fig. 7: Installing the air outlet front

- ▶ When installing the KS, pay attention to the correct installation position, which is indicated by a small label stating "top".
- ▶ Screw the air outlet front to the KS.

KS

Lüftungskomponenten, Kombinationsschlitzdurchlass

Assembly, installation and operating instructions

5.2.3 Adjusting the eccentric rollers

The air stream can be manually adjusted using the eccentric rollers as shown on the diagram below using a slot-head screwdriver.




Fig. 8: Control of the air stream direction

5.2.4 Adjusting the optional volumetric flow limiter

The optional volumetric flow limiter can be manually adjusted by turning as shown below using the scale.




Fig. 9: Setting values

6 Pre-commissioning checks

Before initial commissioning, check whether all the necessary conditions have been met so that the unit can function safely and properly.

Structural tests

- ▶ Check that the unit is securely standing and fixed.
- ▶ Check the horizontal installation/suspension of the unit.
- ▶ Check whether all components are properly fitted.
- ▶ Check whether all dirt, such as packaging or site dirt, has been removed.

Air-side checks

- ▶ Check whether there is unimpeded flow at the air inlet and outlet.

7 Maintenance

7.1 Clean the inside of the unit

The diffusers conform to the Hygiene Directive VDI 6022. They are largely maintenance-free.

Check all elements that come into contact with air (internal surfaces of the unit, outlet elements etc.) for dirt or deposits during maintenance and use a commercially available product to remove.




Fig. 10: Dismantling the air outlet front

- ▶ Dismantle the air outlet front for cleaning.




Fig. 11: Swivelling the acoustic insulation backing

- ▶ Swivel the acoustic insulation backing for cleaning. This also allows the volumetric flow limiter to be accessed.

7.2 Cleaning the volumetric flow limiter




Fig. 12: Clean the volumetric flow limiter.

- ▶ Clean dust and dirt away from the volumetric flow limiter if need be.

www.kampmann.co.uk/hvac/produkte/luftdurchlaesse/ks

Country	Contact
Great Britain	Kampmann UK Ltd.
	Dial House, Govett Avenue
	Shepperton, Middlesex, TW17 8AG
	T +44 1932/ 228592
	F +44 1932/ 228949
	E info@kampmann.co.uk
	W Kampmann.co.uk